



- 1.- INSTALL 4" DIAMETER PVC WELL CASING AND SCREEN INSIDE 6- $\frac{5}{8}$ " WELL TO 165' TOTAL DEPTH.
- 2.- INSTALL 20' OF WELL SCREENS FROM 145'-165'. RUN BLANK CASING TO 1'± ABOVE SURFACE.
- 3.- PLACE GRAVEL PACK FROM BOTTOM TO 50' BELOW GROUND
- 4.- PLACE GROUT FROM 50' BELOW GROUND TO GROUND.

Department of UTILITY SERVICES DIVISION
 4930 ENERGY WAY
 P.O. BOX 11130
 RENO, NEVADA 89520
 Water Resources (702)954-4800



CONVERSION OF DAVID DOMESTIC
 TO MONITORING WELL
 CROSS SECTION

FIGURE 1
 1